
## Floating Joint: Stainless Steel Type

# JS Series



#### Specifications

Operating pressure	Pneumatic cylinder: 1 MPa or less				
	Hydraulic cylinder: 3.5 MPa or less				
Mounting	Basic type				





**Precautions** 

Be sure to read this before handling I the products. Refer to back page 50 I I for Safety Instructions.

#### Mounting

#### ∧ Warning

- 1. For the screw-in depth of the female threads, refer to the dimensions (page 1158).
- 2. The dust cover may adhere to the stud. In this case. move the dust cover at the neck of the stud by the finger or twist the stud slightly left or right to break in the dust cover before use.

Additionally, when screwing the stud and socket or the case into a driven body, screw in such parts with the dust cover removed. When screwing in such parts without removing the dust cover, this may cause damage to the dust cover.

3. To use a floating joint to connect the cylinder rod to a driven body, secure it in place by applying a torque that is appropriate for the thread size. Also, if there is a risk of loosening during operation, take measures to prevent loosening, such as using a locking pin or thread adhesive.

In the event that the connected portion becomes loose, the driven body might lose control or fall off. leading to equipment damage or injury to personnel.

- 4. This product is not a rotary joint. So, the product cannot be used for rotational or rotation acting applications.
- 5. Be sure to use the cushion mechanism of the cylinder or the buffer mechanism, such as the shock absorber so that any impact force is not applied to the floating joint when stopping a driven body. If there is no buffer mechanism, an excessive impact force is generated. As a result, the tensile compression force of the floating joint may exceed its maximum level.


#### Specifications

Specifications									
Model	Applicable bore size (mm)	Applicable cylinder nominal thread size	Maximum operating tension and compression force (N)	Allowable eccentricity U (mm)		pressure Hydraulic cylinder	Ambient temperature		
JS10-4-070	10	M4 x 0.7	80	0.5	1 MPa or less	-	−5 to 70°C		
JS16-5-080	10, 16	M5 x 0.8	210	0.5					
JS20-8-125	20	M8 x 1.25	1100	0.5		3.5 MPa or less			
JS32-10-125	25, 32	M10 x 1.25	2500	0.5					
JS40-14-150	40	M14 x 1.5	6000	0.75					
JS63-18-150	50, 63	M18 x 1.5	11000	1					

Note 1) Think of applicable bore size as a guide. For details, confirm the rod end thread diameter of a cylinder to be used in the catalog.

Note 2) For 3.5 MPa hydraulic cylinders, operate within the maximum tension and compression force.


#### How to Order



Note) 80 80 100 100

Made to Order: Individual Specifications -X530 Note) For details, refer to page 1159

For pneumatic cylinders



Improved sealing

#### Maintenance

### **.**⚠Warning

#### 1. Do not reuse if disassembled.

High strength adhesive is applied to the portion of the connection that is threaded to prevent it from loosening, and it must not be disassembled. If it is forcefully disassembled, it could lead to

