

## Contact Details

Before using the product, please check the guide pages at the front of this catalog.

Internet

<https://www.daikinpmc.com/en/>

For latest information, PDF catalogs and operation manuals

# Stop Valve for Pressure Gauges



## Features

- Installation of this valve enables replacement of the pressure gauge, due to it being damaged for example, without stopping all the equipment. It is also possible to prolong the service life of the pressure gauge by closing the valve except when pressure measurement is required.

## Nomenclature

GV - ※ ※ ※  
 1 2 3 4

### 1 Model No.

(Applicable fluids: petroleum-based hydraulic oils)

GV: Stop valve

### 2 Fluid flow direction

A: Straight

G: Right angle

### 3 Inlet side piping port

2: Rc $\frac{1}{4}$

3: Rc $\frac{3}{8}$

### 4 Outlet side piping port

2: Rc $\frac{1}{4}$


3: Rc $\frac{3}{8}$

## Specifications


Model code	Maximum operating pressure MPa {kgf/cm <sup>2</sup> }	Mass kg
GV-※22	21 {210}	0.4
GV-※33		

## External dimension diagram

GV-G※※



GV-A※※



(Dimensions in parentheses are for GV-G33 or GV-A33.)