Body Ported Type Vacuum Ejector ZH Series



ZK2

ZQ

ZR

ZB

ZA ZX

ZM ZL ZH

ZH

-X267


ZHP

ZU

VQD-V

How to Order

Note Refer to "Table 1" and "Table 2" for the combination available for SUP., VAC. and EXH. port connection.



•	TOLLIC SILC
05	ø0.5 mm
07	ø0.7 mm
10	ø1.0 mm
13	ø1.3 mm
15	ø1.5 mm
18	ø1.8 mm
20	ø2.0 mm
	•

3 Port (SUP./VAC./EXH.) sizeNote)

Inch size

ø1/4"

ø5/16"

ø3/8"

ø1/2'

07

09

11

13

2 Vacuum pressure reached

_	
S	−90 kPa
	-48 kPa (ZH05 to 13D□A)
L	-66 kPa (ZH15 to 20D□A)

4 Accessories (Standard bracket/Silencer)*2

Symbol	Standard bracket	Silencer
Nil	•	×
N	×	×
S*1	•	•
NS*1	×	•

- *1 Options S and NS are not available for EXH. port with a screw-in connection. *2 Each accessory is not assembled with the product, but shipped together.

· Silencer can only be selected for EXH. port with One-touch fitting. · The silencer part number depends on the size of the EXH. port.

EXH. port	Silencer part no.	1	
06	AN10-C06		
07	AN10-C07		
08	AN15-C08		
09	AN15-C08	l	
10	AN20-C10] ;	
11	AN20-C11	Ι,	
12	AN30-C12		

No silencer available for ZH18/20D□A in inch size for EXH. port size '13'. In that case, select the screw-in connection, and order silencer AN30-N03 and AN40-N04 separately

For details about silencers, refer to the AN series in the Best Pneumatics No. 7.

ø12 Female threads

One-touch fittings

ø8

ø10

Metric size

06

08

10

12

metri	C Size		inch size		
01 Rc1/8			N01	NPT1/8	
02	Rc1/4		N02	NPT1/4	
03	Rc3/8		N03	NPT3/8	
04	Rc1/2		N04	NPT1/2	

Refer to "Table 1" and "Table 2" for the combination available for SUP., VAC. and EXH. port connection.

Standard bracket

*3

Applicable model				
	ZH05 to 10D□A	ZH13/15D□A	ZH18/20D□A	
Model	ZH2-BK1A-1-A	ZH2-BK1A-2-A	ZH2-BK1A-3-A	



Table 1 Metric Size

Model	SUP.	VAC.		EXH.	 SUP.	VAC.	EXH.
	06 -	- 06	_	06	 One-touch	One-touch	One-touch
ZH05D□A-	06 -	- 01	_	06	 One-touch	Screw-in	One-touch
	01 -	- 01	_	01	 Screw-in	Screw-in	Screw-in
	06 -	- 06	-	06	 One-touch	One-touch	One-touch
ZH07D□A-	06 -	- 01	-	06	 One-touch	Screw-in	One-touch
	01 -	- 01	-	01	 Screw-in	Screw-in	Screw-in
	06 -	- 06	-	08	 One-touch	One-touch	One-touch
ZH10D□A-	06 -	- 01	-	80	 One-touch	Screw-in	One-touch
	01 -	- 01	-	01	 Screw-in	Screw-in	Screw-in
	08 -	- 10	-	10	One-touch	One-touch	One-touch
ZH13D□A-	08 -	- 02	-	10	One-touch	Screw-in	One-touch
	01 -	- 02	-	02	 Screw-in	Screw-in	Screw-in
	08 -	- 10	-	10	One-touch	One-touch	One-touch
ZH15D□A-	08 -	- 03	-	10	One-touch	Screw-in	One-touch
	02 -	- 03	-	03	Screw-in	Screw-in	Screw-in
	10 -	- 12	-	12	One-touch	One-touch	One-touch
ZH18D□A-	10 -	- 03	_	12	One-touch	Screw-in	One-touch
	03 -	- 03	-	03	Screw-in	Screw-in	Screw-in
	10 -	- 12	_	12	One-touch	One-touch	One-touch
ZH20D□A-	10 -	- 04	_	12	One-touch	Screw-in	One-touch
	03 -	- 04	-	04	Screw-in	Screw-in	Screw-in

*3 Screw-in: Bc female threads

Table 2 Inch Size						
Model	SUP. VAC.	EXH.		SUP.	VAC.	EXH.
	07 - 07	- 07		One-touch	One-touch	One-touch
ZH05D□A-	07 - N01	- 07		One-touch	Screw-in	One-touch
	N01 - N01	- N01		Screw-in	Screw-in	Screw-in
	07 - 07	- 07		One-touch	One-touch	One-touch
ZH07D□A-	07 - N01	- 07		One-touch	Screw-in	One-touch
	N01 - N01	- N01		Screw-in	Screw-in	Screw-in
	07 - 07	- 09		One-touch	One-touch	One-touch
ZH10D□A-	07 - N01	- 09		One-touch	Screw-in	One-touch
	N01 - N01	- N01		Screw-in	Screw-in	Screw-in
	09 - 11	- 11		One-touch	One-touch	One-touch
ZH13D□A-	09 - N02	- 11		One-touch	Screw-in	One-touch
	N01 - N02	- N02		Screw-in	Screw-in	Screw-in
	09 - 11	- 11		One-touch	One-touch	One-touch
ZH15D□A-	09 - N03	- 11		One-touch	Screw-in	One-touch
	N02 - N03	- N03		Screw-in	Screw-in	Screw-in
	11 - 13	- 13		One-touch	One-touch	One-touch
ZH18D□A-	11 - N03	- 13		One-touch	Screw-in	One-touch
	N03 - N03	- N03		Screw-in	Screw-in	Screw-in
	11 - 13	- 13		One-touch	One-touch	One-touch
ZH20D□A-	11 - N04	- 13		One-touch	Screw-in	One-touch
	N03 - N04	- N04		Screw-in	Screw-in	Screw-in
*4 Screw-in: NPT female threads						

