
Compact Manifold Regulator Individual Supply Type ARM5B Series

How to Order



1. Manifold Mounting

Symbol	Α	В
How to mount	Direct mount	DIN rail mount
Appearance		2000

2. Regulator Block Stations

Symbol	Stations
Symbol	
1	1 station
2	2 stations
3	3 stations
4	4 stations
5	5 stations
6	6 stations
7	7 stations
8	8 stations
9	9 stations
М	10 stations



4. Accessory

Mil

Symbol Pressure gauge No

None

Yes


3. IN/OUT Piping Position

Metric s	ize								
Mounting position	IN side					OUT side			
Fitting type	Straight		Elbow		Straight		Elbow		
Symbol	ø4	ø6	ø4	ø6	ø4	ø6	ø4	ø6	
06	•				•				
07		•			•				
08		•				•			
18			•				•		
19				•			•		
20				•				•	
25	•						•		
26		•					•		
27		•						•	
32			•		•				
33				•	•				
34				•		•			

Inch size

Mounting position	IN side				OUT side			
Fitting type	Stra	ight		ow		iight		ow
Symbol	ø5/32	ø1/4	ø5/32	ø1/4	ø5/32	ø1/4	ø5/32	ø1/4
56	•				•			
57		•			•			
58		•				•		
68			•				•	
69				•			•	
70				•				•
75	•						•	
76		•					•	
77		•						•
82			•		•			
83				•	•			
84				•				

Symbol	
Relieving type	
IN 1 2OUT	
IN 1 20UT	8
Non-relieving type	
IN 1 20UT	
IN 1 CT 2 OUT	



OUT side (Back side)

copper-free and fluorine-free specifications.

Symbol	None	0.35 MPa setting Note)	Non- relieving
Nil	•		
1		•	
2			•
3		•	•

Note) Pressure gauges are not compatible with


Note) A pressure gauge with a full span of 0.8 MPa is attached.

7. Unit Representation

Elbow

Symbol	Description		
Nil	Display unit for product name plate and pressure gauge: MPa		
Z Note)	Display unit for product name plate and pressure gauge: psi		

Note) This option is available for use outside Japan only. (The SI units must be used in Japan.)



IN side



ARJ AR425 to 935

ARX

AMR

ARM

ARP

IR□-A

IR IRV

IRV

VEX SRH

SRP

SRF

Configuration

ITV IC

ITVX

PVQ

VY1
VBA
VBAT

AP100